


ATARI® 410™ PROGRAM RECORDER

INSTRUCTIONS FOR PLUGGING IN MODEL 410P (DIRECT CURRENT) PROGRAM RECORDER

An electrical power adaptor is supplied to convert your ATARI 410 Program Recorder to a 410P version for use with direct current. This adaptor, which is packaged separately, is a part of your ATARI 410P Program Recorder purchase. The power adaptor supplies 6 volts direct current at 300 milliamperes and is fitted with a 3.5 millimeter plug. When you use the adaptor, the following instruction will replace Step 2 in the set-up procedure for your ATARI Program Recorder.



2. Hook up the adaptor by plugging the adaptor cord into the jack labeled 6VDC on the side of the Program Recorder. Then insert the power plug into a wall socket.